49-0606

If having issues with oil pressure please remove back screw, spring and ball. Shine a light through as shown. If you can see light through the rear hole pump is defective.