

VT No. 21-0106 Shifter Seal Collar

This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

FLT Grease Elimination Spacer stepped design and O-Ring to replace stock spacer OEM 5702 on shifter shaft on 1980-up FLT models.

Installation: Remove shifters and stock spacer. Stretch O-Ring over the middle of the VT No. 21-0106 spacer. Slide it onto the shaft. Install shifters and roll O-Ring into the shoulder.

Note: Use of 2 spacers or of stock spacer and VT No. 21-0106 allows the removal of the heel portion of the shift pedal assembly.