

**V-Twin Mfg.**

**LONG SHIFTER COLLAR W/WASHER FITS FLT VT No. 21-0107**

**SHORT SHIFTER COLLAR W/WASHER FITS FLT VT No. 21-0108**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Installation Instruction:**

1. With a 3/16: allen wrench, remove the allen bolts from the shifter levers and remove shifter levers from shifter shaft.
2. Remove stock spacer from shifter shaft.
3. Install the new spacer with the counter bore facing the inner primary. Net put shim spring on the shifter shaft with convex facing outward.
4. Loosen the allen bolt on the rear shifter arm and pull the shaft toward you and re-tighten. Next put a screwdriver behind the shifter shaft shift arm to hold shaft from being pushed in.
5. Reinstall Shifter. Note: If your allen bolts were facing down on your shifter levers, turn them over and switch them front to back so they face up. Note: If you're using a toe only spacer eliminate the heel shifter and follow step #6
6. Next place a small piece of wood between the shifter lever and the running board. Push inward applying pressure until the allen bolts drop into place then tighten. Note: Check all other allen bolts on shifter arms, on shifter shaft and transmission shifter arm for proper fitment.