V-Twin MFG. Forward Control Kit FITS 1954-1974 XLH/XLCH VT No. 22-0700

This is a custom application and should only be installed by a knowledgeable and trained motorcycle technician. V- Twin Mfg. accepts no responsibility for improper installation.

XLH-XLCH Forward Mount Kit – This kit contains all parts necessary for installation on all model XLH-XLCH from 1957-76 & 1977-78 mechanical rear brake models only.

Note: Longer Front motor mount bolts may be necessary for installation.

Installation Instruction

- Begin by laying out the hardware required for front motor mounting including the extended motor mount bolts.
- 2. Install the two rear bolts for the front motor mounts.
- 3. Using the extended motor mount bolts (VT No. 7408-10) assemble the backing plate hardware supplied with the kit to the frame and secure.
- 4. Spread the brake components out just the way they'll go on the bike.
- 5. Assemble the components on the motorcycle. Once together adjust the linkage accordingly.
- 6. Lay out the shift components per the diagram included. Note the part #S-4 is not needed on a stock XL frame. Use this part only when installing on a swingarm frame.
- 7. Assemble the shift unit on the bike and adjust accordingly.

