

V-Twin Mfg.  
Chrome FXST Style Brake Kit,  
w/Kelsey Master Cylinder  
VT No. 22-1001

This is a custom application and should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

**Note:** For VT Mfg. kit No. 22-1001 and 22-1018 use Russel Stainless lines VT No. 23-8809 for the front and VT No. 223-8802 from the junction to rear caliper. You will also need to use VT No. 23-0707 brake tee.

Installation Instructions:

1. Mount pedal plate #10 to right side frame boss (4) by (5) bolt through pedal and (2) washer and bolt (3).
2. Number (8) bolt and lock nut act as pedal stop and adjustment.
3. Return spring (11) connects to pedal area (1) and to spring stud (6) which is screwed into mount plate.
4. Plunger pin (7) assemblies to top pedal area (9) for brake plunger (12) activation.

