

V-Twin Mfg.
CHROME EDART FRONT CALIPER KIT
FITS 1988-UP FXSTS
VT No. 23-0953

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instruction:

1. Remove pre-installed bolt (E) from caliper.
2. Install the mounting bracket (A) to the caliper (B) using the 5/16" x 1 1/2" replacement Allen head bolt (C) supplied in the kit.
3. Install the 5/16" x 18 x 3/4" lower Allen head mounting bolt (D).
4. This completes mounting the bracket to the caliper.

