

# **VT No. 26-0188**

## **Front Master Cylinder Cover Kit**

### **INSTALLATION**

#### **NOTICE**

**Do not allow dirt or debris to enter the master cylinder reservoir. Dirt or debris in the reservoir can cause improper operation and equipment damage.**

1. Clean front master cylinder cover. Remove two screws that hold the cover in place. Remove over assembly.
2. Replace the original cover assembly with new cover assembly.

#### **NOTE**

**The cover is labeled for DOT 5 silicone brake fluid. Install this cover on reservoirs filled only with DOT 5 silicone brake fluid. Do not mix grades of brake fluid as they are not compatible and could cause equipment damage.**

3. Put new cover and gasket in position.
4. Install new cover screws. Tighten the two screws evenly and securely to 1.3-1.7 N·m (12-15 in-lbs.).