

VT No. 27-0566 3" Forward Control Extension for 2000-up Softails & Deuces

Parts Included

Qty	VT No.	Item
2		Backing Plates (1 left & 1 right), (black) Left hand Plate has small hole for kickstand spring
2		Spacer Plates (aluminum)
1		Shift Rod, which is made from 303 stainless steel and can be polished and chromed
6		3/8 - 16 x 1 1/4" cap screws
12		3/8 Flat washers
6		Nylock Nuts
2		3/8 -16 x 3/4" Countersunk Socket Head Screws

- Secure bike in an upright position.
- Use Lock-tite on all fasteners.
- Remove the existing shifter, shift rod and kickstand.
- Install the new backing plate (the one with the small hole on bottom for kickstand spring), and reinstall the shifter assembly and extension plate.
- Kickstand spring needs to be hooked from the backside of the extension plate.
- Install an extended shift rod (13.5").
- Remove the existing brake side assembly, and install the new backing plate to the frame.
- Reinstall the brake assembly with the corresponding aluminum spacers in between the brake assembly and extension, and install a new brake hose.
- Bleed brake line and caliper.

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

