

VT No. 27-0670 Chrome Telescopic Kickstand Kits with Spring Loaded Ball Bearing Lock

1. Mount complete kickstand assembly to your frame using the supplied hardware.
2. In order to adjust the length of the kickstand, loosen the kickstand nut, turn the kickstand shaft to the desired length. Make sure the foot of the kickstand assembly pivot bolt. Tighten the nut securely using the supplied loctite. (If the threads of the kickstand shaft are exposed, you must re-adjust the assembly until threads are no longer showing.)
3. Install locking set screw into the backside of the kickstand using the supplied loctite.

This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.