

## **VT No. 27-0832 and 27-0833**

1. Place motorcycle securely on lift or side stand.
2. Remove the factory sprocket cover. Note: Some components such as exhaust and brackets may need to be removed. Consult your manual for specific instructions.
3. Use medium strength thread locker on supplied 1/4-20 and 3/8 -16 socket head bolts.
4. Install Outlaw Belt Guard using supplied spacers. Torque the 3/8-16 bolt to 30-33 ft-lbs and 1/4 -20 bolt to 80-120 lbs.
5. Reinstall any components that were removed.