

FOOTBOARD HEEL GUARD
VT No. 27-00837

INSTALLATION

1. Remove the rubber insert from right footboard. Save for later installation.
2. Remove right side OE footboard.
3. Fit heel guard to foot board use the screw (7) and tab (8) to align the footboard as pictured.
4. Use the fastener tab (5) as a template to mark the drill hole location. Remove footboard and drill a 0.281 (9/32) diameter hole in footboard base.
5. Install Heel Guard to footboard using supplied hardware.
6. The rear tab should rest against the rear footboard support and fastened to the support using hardware previously removed.
7. Install rubber footboard pad.