

**V-Twin Mfg.
Adjustable Passenger Footboards
VT No. 27-1522
(Footboards sold separately)**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. If OEM Footboards are installed, remove the Footboard from the OEM mounts. Carefully raise the rubber corners of the Footboards at the pivot pins. (See figure 1). **Do not remove the rubber from the Footboards.** Push the pins outboard until free (See Figure 2).
2. Remove the Footboards support brackets from the Motorcycle.

Note: The right and left brackets are reversible, but only adjustable in the range of 0 to 90 degrees depending on location preference. (See Figure 3) or 270 to 360 degrees (See Figure 4). Select the angle and height preferred before mounting the footboard mounting brackets.

3. Install the new mounting brackets using the hardware provided in the kit. Tighten to 30-35 ft-lbs.

Note: On motorcycles with no previous footboards the plastic plug will need to be removed exposing the threaded hole.

4. Install the footboards on the new brackets. Loosen the mounting bracket adjusting bolts and adjust as desired. Tighten to 22-28 ft-lbs.



Figure 1



Figure 2



Figure 3



Figure 4