

V-Twin Mfg.
Solo Seat Mount Kit
Fits 1980-1992 FLT; Includes "T" Bracket
VT No. 31-9050

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

FLT Seat "T" Mount Kit provides installation of Police solos, and Buddy seat on 1979-up FL T models pre 1987 require drilling and tapping three 1/4x20 holes in rear of tank, on later models holes are predrilled and tapped.

Instructions:

1. Seat T bracket 1 piece.
2. 1/4x20 X 3/4 mount bolt 3 piece, 1/4x20 split lock washer 3 piece; on pre 1987 models these 3 holes must be drilled and tapped 1/4x20.
3. Spring perch mount screws 5/16 x 24 x 3/4 Hex cap 2 piece Nylock nut #11 (5/16 x 24) 2 piece.
4. 3" Tube spacers 2 piece.
5. 2" Chrome seat springs.
6. Front mount bracket.
7. 5/16 x 24 x 3" Hex cap screw 2 piece, 5/16 x 24 Nylock nut 2 piece.
8. 5/16 flat washer 2 piece.
9. Frame cover #16 mounts to existing bolts for saddle bag guards at location.
10. 5/16 x 24 Nylock nut 2 piece.
11. Spring mount bracket Black.
12. 3/8 x 24 x 2 seat tee front bolt.
13. 3/8 x 24 Nylock nut 1 piece #13.
14. Gas tank rear cover strip use the existing bolt.
15. Frame Cover; Black with edging 1 piece.

