

V-Twin Mfg.
SPOTLAMP BRACKET KIT
Fits 1980-UP FXWG,FXST
VT No. 31-9913

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation:

1. Secure top hole on bracket to top triple tree using spacer between tree and bracket.
2. The offset mount brackets attaches to the lower fork stem pinch bolts.
3. The spot light bracket lower mount holes are secured to tapered holes on lower pinch bolt brackets.
4. Be sure to use lockwashers provided during assembly.