

V-Twin Mfg.
Volt Tech Turn Signal Load Equalizer
VT Part No. 32-0874

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

NOTE: This equalizer will work on all LED lights wired into the turn signal system.

Installation Instructions:

1. Place bike on center stand.
2. Remove rear fender per service manual instructions.
3. Locate the turn signal wires. Identity the positive wire for the left and right side turn signals.
4. Wire the red wires from the load equalizer into the turn signal system of the bike by crimping the supplied T-taps on each wire and plugging the red wires into the taps. One wire goes to the left side turn signal and the other wire goes to the right side.
5. Wire the black wire from the load equalizer into any ground wire in the same manner.
6. Attach the load equalizer to a secure place on the bike where the wires will not interfere with moving parts.

