

V-Twin Mfg.
Radii Chrome Oval Tail Lamp Assembly
VT Part No. 33-0391

This is a custom application and should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation

Knowledge of basic wiring is essential to the successful installation of this product. Refer to the maintenance manual for the wiring diagram of your specific model motorcycle. The wire colors referenced are typical but **should always be verified**.

1. Remove the OEM tail light lens
2. Unplug all the sockets from the tail light assembly
3. Remove the OEM tail light assembly from the bike.
4. Remove the OEM turn signal assemblies from the bike
5. Install the tail light mount Part #31-3192
6. Splice the wires as shown below.

NOTE: Yellow wires on tail light assembly are for turn signals. Test to see that the correct sides (left/right) are wired to the correct signal

7. Install the tail light assembly with provided hardware.

Color	OEM Color
Red Running lights	Blue
Blue Brake	Red/yellow
Black Ground	Black
Yellow LT = (turn)	Violet Lt
Yellow RT = (turn)	Brown RT