

V-Twin Mfg.
Bullet style Turn signal w/Amber Lens
VT Part No. 33-0465

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

This part is for use on the following models: 1994-2008 Touring FLHT, FLHTC, FLHTCU, FLHR,FLHRC and 1996-2008 Softail FLSTC, 1998-2003 FLTR, 1993-1996 FLSTN(except FLHX)

Installation Instructions:

Refer to the service manual on turn signal removal. Save all hardware for reuse. Be sure to record the wire color and its location in the AMP connector. Use mechanics wire to pull each old wire through the conduit. Then attach the new wire and pull it back through the conduit. If this is not possible, use wire ties to secure the new wires alongside the conduit.

1. Remove the OEM front turn signal assemblies.
2. Remove the wires from the AMP connectors (note the color) and attach mechanics wire to the terminal ends.
3. Pull the wire out of the conduit with the mechanics wire attached.
4. Using the mechanics wire reverse the procedure and install the new assembly wires (note wire color)
5. Re install the AMP connector and connect the new connectors to the harness.
6. Install new wire ties as necessary.
7. Repeat the steps for the rear turn signal assemblies.