

**V-Twin Mfg.**  
**7" Headlamp Chrome Frenched Trim Rim**  
**VT No. 33-0547**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

These kits fit 1983 and later Touring motorcycles (except Tour Glide and Road Glide). Kits also fit 1994 and later FLHR models, and 1986 and later FLST models with accessory Chrome Headlight Nacelle

**Installation Instructions:**

1. Loosen original equipment trim ring screw.
2. Slip new trim ring over original equipment trim ring. The lip on the back of the accessory ring should slip between headlamp housing and original equipment trim ring.
3. Tighten original equipment ring screw.
4. Tighten accessory trim ring screw.

