

V-Twin Mfg.
Dual Air Horn set with Compressor
VT Part No. 33-1909

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Disconnect the battery.
2. Locate a suitable place to mount the horn and compressor. A bracket and hardware is provided that may be used.
3. Locate a suitable place to mount the relay. The relay should be mounted away from extreme heat.
4. A plug is available from V-Twin to aid in the wiring process. Use VT # 32-8041 or 32-8042.
5. Install the hose provided in the kit between the compressor and the air horn set. Be sure to route the hose away from exhaust and extreme heat.
6. Install the wiring as shown in the diagram. Be sure to route the wiring away from exhaust and extreme heat.
7. Connect the battery.
8. Press horn switch to test.

