

V-Twin Mfg.  
Accel Hi-Flow Chrome Petcock Straight with Nut  
VT Part No. 35-9171  
Accel Hi-Flow Chrome Petcock 90° with Nut  
VT No. 35-9074

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

**Installation Instructions:**

1. Drain fuel tank(s) and remove old valve.
2. Install the ACCEL valve is into the fuel tank in the same manner as the OEM valve.
3. Thread nut to lowest position on valve (LH thread). Be sure the teflon washer is in the inside of the nut resting on top of the valve.
4. Place the valve on the fuel tank bung (RH thread), and thread the fuel tank nut onto the tank bung until tight.
5. For the 35-9074 **only** to prevent damage to O-rings, and possible leakage, **DO NOT REMOVE** hose barb from stem. Determine the best position for the hose barb, then tighten Nyloc nut on the bottom of the valve. Proceed to connect the fuel hose.

