

VT No. 38-0387 and 39-0380

Route wires along frame to speedo/tach mounting area. Trim wires and conduit to proper length and terminate ends of both red and orange wires. Connect red wire to "trig" stud on tach. Connect orange wire to "ign" studs on tach.

