

**V-Twin Mfg.  
Chrome Dress Up Kit  
For Use on 2004 and up XL Models  
VT No. 42-1051**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Installation Instructions:**

1. Remove only the bolts shown in these instructions. (see pictures)
2. Install the new dress up covers using the provided bolts. Be certain to use the bolts of proper length.
3. On the left side, the clutch cable and shifter linkage will need to be removed. Refer to the service manual for instructions.
4. Replace the belt cover and hardware with the one provided. See service manual for instructions.

