

VT No. 43-0388 and 43-0389

1. Place motorcycle securely on lift or side stand.
2. Remove the factory sprocket cover. Note: Some components such as exhaust and brackets may need to be removed. Consult your manual for specific instructions.
3. Use high strength thread locker on supplied 1/4-20 socket head bolts and install Out-law Pulley Cover with supplied spacers. Torque bolts to 90-120 in-lbs.
4. Reinstall any components that were removed.