

V-Twin Mfg.
Complete Spring Fork Damper Kit
VT Part No. 49-1951, 49-1952, 49-1953 & 49-1955

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

Assemble in the order shown in the illustration below. Be sure torque arm engages properly with frame head. Lips on pressure disc must fit into slot in fork Crown and slot in rod lock plate. Turn actuating sleeve all the way into fork stem and then back it up 1/2 turn or more. Register operating lever on actuating sleeve and see that lever has full left movement without bottoming sleeve.

Adjust by setting adjusting nut so -that operating lever must be moved nearly straight back from free (left side) position, before damper takes noticeable effect then tighten lock nut.

