

FAIRING BRACKET KIT VT No. 50-0616, 50-0617

GENERAL

Installation Requirements

Loctite® 271 Threadlocker and Sealant - Blue (OEM# 99671-97) to secure the screws.

WARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a dealer perform the installation. Improper installation of this kit could result in death or serious injury.

NOTE

This instruction sheet refers to service manual information. A service manual for this year/model motorcycle is required for this installation.

INSTALLATION

1. Follow service manual to remove the existing support brackets.
2. Follow service manual to install the new support brackets.