

59399-48-Set.
3724-48-Set,

59215-48-Front,
3724-48A-Front,

59885-48-Rear
3724-48B-Rear

Template with which to locate holes in fenders for attaching chrome fender tips.
Cut out template, place on fender, center punch, and drill as indicated.

HARLEY-DAVIDSON MOTOR COMPANY

MILWAUKEE 1, WIS., U. S. A.

DRILL $\frac{9}{32}$ DIA. HOLES IN FENDER

