

CUT OUT TEMPLATES, TAPE TO FENDER, CENTER PUNCH HOLES,
REMOVE TEMPLATES, THEN DRILL 7/32" HOLES

For use on stock
1949-57 Rigid Rear Fender only,
or VT No. 50-0142, 50-0744

