

VT NO. 50-1220 & 50-1221

FRONT FENDER SKIRT KIT

INSTALLATION

Replacement Skirt Installation

1. Remove screws, washers and nuts securing existing fender skirt to fender. Discard fender skirt and hardware.
2. Clean the fender in the skirt mounting area with a mixture of 50 percent isopropyl alcohol and 50 percent distilled water. Allow to dry completely.

NOTE

Install the **new** washers on the **inside** of the fender.

3. Get the **new** fender skirt, fender skirt mounting screws, washers and nuts from the kit. Align the fender skirt as shown. Install skirt to fender, but do not fully tighten.

Follow the tightening sequence in Figure 2 inset. Press the fender skirt firmly against the fender at each hole in turn while tightening the mounting hardware to 10-15 **in-lbs**.

Clean Fender Installation



Do not contact tire with drill bit when drilling fender holes. Drill bit contact with tire can lead to premature tire failure, which could result in death or serious injury.

NOTE

To install this skirt kit on a Clean Front Fender, perform the following:

1. Clean the fender in the skirt mounting area with a mixture of 50 percent isopropyl alcohol and 50 percent distilled water. Allow to dry completely.
2. Cover **that** portion of fender with masking tape to protect painted surface during positioning of skirt and drilling of mounting holes.
3. Place fender skirt in desired location and mark mounting hole locations with felt tip pen. Align the lower edge of the fender skirt parallel to, but slightly below the lower edge of the fender.
4. Remove fender skirt. Carefully center punch holes at marked locations.
5. Drill mounting holes using a 1/8 in (3 mm) diameter drill bit.
6. Remove masking tape. Attach fender skirt.