

**V-Twin Mfg.**  
**CHROME SISSY BAR SIDE PLATE SET**  
**VT Part No. 50-1556**

**For use on 1997-2008 FLHR, FLTR, FLHX Models**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Note:** Caution should be taken to protect the paint surface. Use Locktite on all hardware.

**Installation Instructions:**

1. Remove both the right and left side saddlebags. Place a motorcycle lift or jack under the motorcycle. Raise the motorcycle to relieve the weight off of the shock attachment bolts.
2. Remove the upper bolt securing the shock to the motorcycle (Do one side at a time). The shock may be pushed forward if necessary, take precaution to protect the paint.
3. Remove the top rear fender strut/saddlebag torx bolt. The torx bolt will not be re-used.
4. Align the side plate holes over the fender strut and reinstall the shock bolt through the front hole of the side plate. Using the 2 inch bolt, spacer and washer supplied with the kit, attach the back end of the side plate to the strut/saddlebag support.

**NOTE:** To allow for easy movement of the side plates, do not tighten any of the bolts until the sissy bar is installed.

5. Repeat the steps above on the opposite side of the motorcycle.
6. Install the sissy bar (sold separately) using the hardware provided.

**NOTE:** These side plates will fit most sissy bars with 8-3/4 width.

7. Torque the top shock bolts and the remaining hardware to OEM specifications.
8. Lower motorcycle and re-attach the saddlebags.



**Parts List**

Qty	Description
2	side plates ( R & L )
2	5/18-18X 2 bolts
2	5/16 flat washer
2	1-1/4 spacers
4	1/4-20 X3/4 allen bolt