REAR SADDLEBAG GUARDRAILS VT No. 51-0850 and 51-0851

Installation Requirements

Separate purchase and installation of additional parts or accessories may be required for proper installation of this kit on your model motorcycle.

WARNING

The rider's safety depends upon the correct installation of this kit. If the procedure is not within your capabilities or you do not have the correct tools, have a dealer perform the installation. Improper installation of this kit could result in death or serious injury.

NOTE

This instruction sheet references service manual information. A service manual for your model motorcycle is required for this installation.

Kit Contents

See Figure 1 and Table 1.

INSTALLATION

Kit Number 49087-01

- 1. Remove and save fasteners that retain saddlebag guardrails.
- 2. Replace stock saddlebag guardrails with new guardrails from kit.
- 3. Screw in and torque each stock fastener as follows:
- a. Four stock screws, Part No. 3678, using two new locknuts (1), Part No. 7667. Tighten each screw to 25.7 N·m (19 lb.ft.).
- b. Two stock screws, Part No. 3601 using two new locknuts (2), Part No. 7686. Tighten each screw to 12.2 N·m (9 lb.ft.).

Kit Number 49088-01

- 1. Remove and save fasteners that retain saddlebag guardrails.
- 2. Replace stock saddlebag guardrails with new guardrails from kit.
- 3. Using four hex socket button head screws (8) removed earlier, attach saddlebag guards using the remaining two existing holes in each guardrail.
- 4. Install and tighten each stock fastener.
- a. Four stock screws, Part No. 3678, using two new locknuts (5), Part No. 7667. Tighten each screw to 25.7 N·m (19 lb.ft.).
- b. Two stock screws, Part No. 3601 using two new locknuts (6), Part No. 7686. Tighten each screw to 12.2 N·m (9 lb.ft.).

SERVICE PARTS

Figure 1. Rear Saddlebag Guardrails

Table 1. Service Parts

Item Description (Quantity)

Rear Saddlebag Guardrail Kit 49087-01

- 1 Locknut (2)
- 2 Locknut (2)
- 3 Guard assembly, rear, right

Guard assembly, rear, left (not shown)

