

**V-Twin Mfg.  
Chrome Front Engine Guard  
Fits 1988-1996 FLT Models  
VT Part No. 51-0880**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Installation Instructions:**

1. Remove bolts (1) washers (2) and nuts (3) from lower mount tabs on the left and right side of the engine guard (4). Save all hardware for reassembly.
2. Remove bolt (5) and washer (6) from the upper mount tab on the guard (4) and remove guard from the motorcycle. Save washer (6) but discard bolt (5).

**Note:** On 1988 to 1992 models, a new bolt is included with the engine guard kit and must be used on upper mount tab when installing the new engine guard kit. The old bolt was fine thread and new bolt is coarse thread.

3. Install the new guard using screws (1), washers (2) and nuts (3) removed in Step 1 on the lower left and right mount tabs of the new engine guard.
4. Use the new bolt (5) from kit and washer (6) removed in Step 2 on upper mount tab on the guard.

1. Bolt (2)
2. Washer (4)
3. Nut (2)
4. Engine Guard
5. Bolt (1)
6. Washer (1)

