



BT Mechanical Brake



1936-57 BT Mechanical Kit is perfect for finishing a restoration or for forward controls on the rigid frame custom. For use on mechanical brake frames with a cross shaft tube only. Hardware included. Footboards may be used with this kit.

VT No.	Type
22-0706	Chrome
22-0707	Parkerized



Brake Shoe Sets fit 1937-57 Big Twin Rigid and are complete with linings installed. Sold in pairs. Note: When new shoes are installed, they may have to be "arced" as described in restoration guide, VT No. 48-1738, page 24. 23-1795 shoe sets are fit to our drums.

Mechanical, Rear.

VT No.	Type
23-0500	Stock
23-1795	Arced, 12 1/8" long, 1 9/16" wide
23-1750*	Cast

*Note: Original Cast Construction

Brake Linings With Rivets

VT No.	Type	Fits
23-0504	Rear 1938-57	Big Twins
23-0505	Front 1949-72	Big Twins
23-0450	Front 1949-72	Big Twins, .025 Oversize
23-1987	Rear 1963-72	Big Twins
23-1989	Rear 1958-62	Big Twins
23-0516	Front	BT Springer Type Fork
23-0518	Front	1935-52 45"
23-0736	Rear 1941-46	45" Solo



Clutch & Brake Brass Rivets.

VT No.	Type	Use	U/M
37-8805	Short 4-4 1/2	Brake	
37-8806	Long 4-5	Brake	100
37-8807*	Short 7-4	Clutch	100
37-8808	Long 7-5	Clutch	100
23-0522	1974-76F Br	ake	10

*Note: For clutch hub friction disc.



Mechanical Backing Plate Kit for 1936-57 includes plate, springs, shoes, cam pivot stud and plate. Arm not included.

VT No.	Replica	Finish
22-0708	22-0745	Chrome
22-0709	22-0746	Black



Rear Brake Drum Kits feature backing plate with all components installed, including a pre-arc'd set of brake shoes to fit the drum supplied. The drum has the 51 tooth sprocket riveted on with an original style dust ring. Kits are available in black or chrome finish. Lug bolts included, but axle and sleeve kit must be purchased separately.

VT No.	Finish
23-0876	Black
23-0877	Chrome

1958-69 Brake



1958-69 Hydraulic Brake Kit includes all parts illustrated as replacement for flat side motors or for use on cone motors with an outside frame pipe. Available with or without cast iron Wagner style master cylinder



VT No.	Master Cylinder
22-0401	Without
22-0403	With Chrome
22-0402	With Painted

1958-69 Big Twin Rear Brake Components.

VT No.	Item	Finish
23-0100	Pedal	Chrome
23-0101	Pedal Plate	Chrome
23-1742	Spacers	Zinc
13-0147	Spring	Chrome
13-0175	Spring	Chrome
23-0115	Plunger	Chrome



Foot Brake Lever & Bracket Mounting Kit includes nut, washers and bolts are duplicates of stock hardware for 1936-71 Big Twin.

VT No.	Finish
9732-7	Chrome
9733-7	Cadmium
9734-7	Parkerized



Master Cylinder Cover fits 1958-78 Big Twin.
VT No. 42-0315