



Chrome or Zinc Plated Rear Shock Studs, with cup washers. Each kit includes 2 studs and 4 chrome plated cup washers. Note: Cup washers and lock nuts may be purchased separately.

chased separately.

Upper Pair

Chrome	Zinc	OEM	Fits
54-0442	54-0416	54515-73	1973-84 FL-FX

Lower Pair

54-0401	3958	1973-84 FL-FX
---------	------	---------------



Shock Stud Conversion allows use of shocks with 1/2" holes with steel inserts. Simply press out stock bushing and sleeve, replace with the 2-piece style. Fits the 5/8" dia. studs on many models. Use a 5/8 cup washer for final assembly. Set of 8 rubbers.

VT No.	Item
28-0133	Rubber Bushing
54-0418	5/8 Cup Washers, 10 pack



Lower Shock Stud Kit includes two nugget nuts & 2 studs. Fits 1973-84 FX. Replaces 3958.
VT No. 54-0401



Shock Bushings fit 1958-84 BT, 10 pk. Replaces OEM 85210-42A.
VT No. 28-0220



Shock Stud Washer 10 pack.

VT No.	OEM	Type	Finish
54-0418	54544-65	5/8" Hole Cup	Chrome
54-0419	54543-65	3/8" Hole Cup	Chrome
54-0420	54545-65	1/2" Hole Cup	Chrome
54-0421	6718	1/2" Hole x 1" Flat	Chrome
54-0424	6722B	5/8" Hole x 1.3" Flat	Zinc
54-0432	6415B	3/8" Hole x 1.25" Flat	Zinc



Nylock shock stud nut is 5/8-18, replaces 7993.

VT No.	Finish	Qty
54-0422	Zinc	10
54-0447	Chrome	4

Shock Studs



V-Twin™ Shock Stud Kits include all pieces for upper and lower positions. Including washers, nuts and lockwashers as necessary. Studs and bolts are zinc plated. Outer nuts and washers are chrome.

VT No. Year

54-0466 1958-64 *Note: with chrome studs.

54-0464 1958-64

54-0463 1965-66

54-0462 1967-72

54-0465 1973-84

Chrome or Zinc Plated Rear Shock Studs, with cup washers. Each kit includes 2 studs and 4 chrome plated cup washers. Cup washers and lock nuts may be purchased separately.

Upper Pair

Chrome	Zinc	OEM	Fits
54-0445	54-0408	54515-58A	1958-64 FL 3/8" thread
	54-0409	54515-65	1965-66 FL
54-0440	54-0410	54515-67	1967-72 FL-FX


Lower Pair

54-0446	54-0411	54517-58	1958-64 FL
	54-0413	54517-65	1965-66 FL
54-0441	54-0412	54517-67	1967-72 FL-FX



Stock Stud Spacers replace 5960W on 1965-85 FLH when rear frame bars are not used. Zinc plated, pair.

VT No. 54-0425



Replacement Hardware fits stock or aftermarket shocks 1967 later, top clip type.

VT No.	OEM	Item	U/M
54-0204	54558-73	1973-84 Cam Lower	Pair
54-0203	54559-73	Cam Sleeve	Pair
54-0205	54635-73	Spring Retainer	Pair
54-0429	54700-67	Upper Cover	Pair
54-0201	6910W	Washer	10 pk

