



Chrome Front Engine Bar

FOR ENGINE BARS LISTED ON THIS PAGE

WARNING: ENGINE/FRAME BARS MAY PROVIDE LIMITED LEG & COSMETIC VEHICLE PROTECTION UNDER UNIQUE CIRCUMSTANCES (FALL OVER WHILE STOPPED, VERY LOW SPEED SLIDE). THEY ARE NOT MADE NOR INTENDED TO PROVIDE PROTECTION FROM BODILY INJURY IN A COLLISION WITH AN AUTOMOBILE OR ANY OTHER OBJECT.



51-0881
1982-03
style



51-0886
1956-81
style



51-0939



51-0985
Installed



31-0599

XLH-XLCH 1 1/4" Diameter

VT No.	OEM	Fits
51-0886	49042-56A	1956-81
51-0881*	49018-88C	1986-03
51-0939	49060-04	2004-up
51-0985	W/Pads	2004-up

31-0599 Replacement Black Bracket for 51-0811

*Note: Includes chrome bracket for use with forward controls



27-0587

Mega Footpeg Kit features Billet clamp set to attach to 1 1/4" engine bars.

VT No.	Item
27-0587	Footpeg Kit
27-0698	Bracket Set



50-2067 Installed

Lindby Custom Front Highway Bars with footpegs feature 1 1/4" tubing and built in O-Ring pegs. Fit all 1986-up XL models without forward controls.

VT No.	Fits
50-2067	2004-up
50-2068	1986-2003
14-0977	Replacement O-Ring



27-0660
Installed

27-0654 Mounts only

Chrome Billet Engine Bar Footpeg Mount Kit fits on 1 1/4" front engine bars with male pegs.

VT No.	Item
27-0660	Kit
27-0654	Mounts Only



27-0032

Chrome Footpeg Mount Kits include clamp set and extension bars to accept male pegs.

VT No.	Size
27-0032	1"
27-0033	1 1/8"
27-0034	1 1/4"



Bar Clamps fit 1 1/4" engine bars to mount male footpeg sets.
VT No. 27-0892



Footpeg Mount Kit allows male-type pegs to be mounted to 1 1/4" diameter engine bar.

VT No. 27-0651