



Shock Stud Kit



54-0152



54-0509



54-0153



54-0532



54-0514



54-0124

Chrome Upper Shock Stud Covers.

VT No.	OEM	Years
54-0152	54704-65	1965-74
54-0153	54704-75	1975-78
54-0514	57408-88T	1982-90
54-0509	54712-94	1991-99
54-0532	54616-96	1991-2003
54-0124	54724-04	2004-up



54-0417



2406-10



2405-10

Chrome or Zinc Plated Rear Shock Studs with cup washers. Each kit includes 2 studs and 4 chrome cup washers. Cup washers and lock nuts may be purchased separately.

Upper Pair

Chrome	Zinc	OEM	Year
54-0443	54-0414	54515-56B	1956-74
—	54-0417	544515-75	1975-78
—	54-0455	47384-91	1991-93
—	54-0457	47384-94	1994-up

Lower Pair

54-0444	54-0415	54516-72	1956-74
—	54-0405	54516-75	1975-78
54-0430	—	4081	1982-91

Upper-Lower

2406-10	—	—	2000-03
2405-10	—	—	2004-up



Shock Stud Washer 10 pack.

VT No.	OEM	Type	Finish
54-0418	54544-65	5/8" Hole Cup	Chrome
54-0419	54543-65	3/8" Hole Cup	Chrome
54-0420	54545-65	1/2" Hole Cup	Chrome
54-0421	6718	1/2" Hole x 1" Flat	Chrome
54-0424	6722B	5/8" Hole x 1.3" Flat	Zinc
54-0432	6415B	3/8" Hole x 1.25" Flat	Zinc



Nylock shock stud nut is 5/8-18, replaces 7993.

VT No.	Finish	Qty
54-0422	Zinc	10
54-0447	Chrome	4



54-0460



54-0403



54-0448



54-0449



54-0450



54-0451

V-Twin™ Shock Stud Kits include all pieces for upper and lower positions. Including washers, nuts and lockwashers as necessary. Studs and bolts are zinc plated. Outer nuts and washers are chrome.

VT No.	Years	VT No.	Years
54-0460	1956-74	54-0449	1982-85
54-0403	1975-78	54-0450	1986-90
54-0448	1979-81	54-0451	1991-2001



54-0403

Shock Stud Conversion Stud Kit updates 1954-74 to late model bushing diameter of 1/2". Kit includes 4 studs, 4 nuts and 8 washers and top covers. Use with VT No. 54-0106 with 1/2" holes.

VT No.	Item
54-0403	Kit
28-0231	Bushings 1/2" I.D.



Chrome Shock Covers are a 1950's style top cover. Fit all models of swing arm with stock shocks including 1952-78 Sportster. Some seats may cause interference.

VT No. 54-0154



Chrome Lower Shock Covers give the Big Twin look on XL models 1979-up with Showa shocks. Covers install easily without dismantling the shock.

VT No. 54-0206



16-0101

16-0409

16-0100

Shock Tool.

VT No.	OEM	Years
16-0101	94820-75	1975-78
16-0409	94409-78	1979-up
16-0100	94700-65	1952-74