

## **VT No.12-0159**

### **Installation Instructions**

1. Install cork in bottom of tappet screen in case
2. Install screen in housing
3. Install housing with screen in tappet screen hole in case
4. Place ball on top of tappet screen housing
5. Install brass washer on plug
6. Install spring into plug
7. Thread plug into case and tighten