

**V-Twin Mfg.
39 mm Fork Brace
VT Part No. 24-0841**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

These kits are designed for installation on 39mm diameter forks on the following models and model applications. 1988 and later XL, 1987 FXLR and FXRS-SP, and all FXR (except FXRT), and FXD Dyna models (except FXDWG models)

NOTE - These brace kits are not recommended for forks with chrome lower fork legs.

1. On models equipped with 39mm forks, the fork brace fits over the dust cover.
2. Using allen wrenches, remove screws and end caps from brace halves.
3. Loosen screws push brace halves together and insert between fork tubes. Heads of screws must face towards the engine.
4. Make sure brace is down tight on dust covers on 39mm fork equipped models and install end caps. Lightly secure end caps with screws.
5. Align brace halves tighten screws finger tight.
6. Push down on front forks several times to seat fork brace and allow it to self-align.
7. Tighten end cap screws and brace screws.

It is very important to tighten all screws evenly and carefully to prevent binding.

Check clearance between fork brace and front end components such as brake hoses and cables. Check all clearances throughout the full travel range of the front suspension. Insufficient clearance may lead to loss of control of vehicle which could result in death or serious injury.