

V-Twin Mfg.
41mm Chrome Fork Brace
VT Part No. 24-0842

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Fits 1993 and later FXDWG, 1999 FXSTB, and 1984 and later FXSTC Models.

Installation Instructions:

1. On all models except those equipped with 41mm forks, push the dust covers off of the sliders and up the fork tubes until out of the way. On models equipped with 41 mm forks, the fork brace fits over the dust cover.
2. Using allen wrenches, remove screws (1) and end caps (5 and 6) from brace halves (3 and 4).
3. Loosen screws (2), push brace halves together and insert between fork tubes. Heads of screws (2) must face towards the engine.
4. Make sure brace is down tight on fork sliders (dust covers on 39mm fork equipped models) and install end caps (5 and 6). Lightly secure end caps with screws (1).
5. Align brace halves (3 and 4) tighten screws (2) finger tight.
6. Push down on front forks several times to seat fork brace and allow it to self-align.

Note: It is very important to tighten all screws evenly and carefully to prevent binding.

7. Tighten end cap screws (1) and brace screws (2).
8. Slide dust covers down onto fork brace (except 39mm fork equipped models).