

GENERAL

56165-03

Installation Requirements

WARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a dealer perform the installation. Improper installation of this kit could result in death or serious injury.

NOTE

This instruction sheet refers to service manual information. A service manual for this year/model motorcycle is required for this installation.

Kit Contents

There are no service parts available for this kit.

INSTALLATION

NOTE

Cover painted parts to protect finish.

1. 2013 and Earlier Touring Models: 2014 and Later Touring Models:

ALL Other Models:

- a. See the service manual to remove the fairing.
- b. Remove and retain the two cap screws beneath the upper fork bracket that hold the existing lower handlebar risers in place.
- c. Move the handlebar assembly from the installed position. Carefully allow gauges and handlebar to rest on vehicle.
- d. Remove and discard cup washers, rubber bushings and spacers.
- a. See the service manual to remove the fairing.
- b. Remove and discard the two cap screws beneath the upper fork bracket that hold the existing lower handlebar risers in place.
- c. Move the handlebar assembly from the installed position. Carefully allow gauges and handlebar to rest on vehicle.
- d. Remove and discard cup washers, rubber bushings and spacers.
- a. Remove and retain the two cap screws beneath the upper fork bracket that hold the existing lower handlebar risers in place.
- b. Move the handlebar assembly (from the installed position). Carefully allow gauges and handlebar to rest on vehicle.
- c. Remove and discard cup washers, rubber bushings and spacers.

NOTE

The new upper and lower bushings must be oriented with the larger diameter ends opposite each other as shown.

2. Install the new polyurethane riser bushings in place of the removed cup washers, bushings and spacers.

3. Align components.

4. 2014 and Later Touring Models: Secure components with two new hex head cap screws. Insert the cap screws, from the bottom, through the upper fork bracket, through the bushings and into the handlebar risers. See the service manual for torque specification. ALL Other Models: Secure components with two hex head cap screws removed in Step 1. Insert the cap screws, from the bottom, through the upper fork bracket, through the bushings and into the handlebar risers.

01.24.2017