

V-Twin Mfg.

Header Sets

VT No. 30-0187, 30-0622, 30-0630, 30-0640, 30-0671, 30-1273, 30-1274

HINT: CLEAR EXHAUST PARTS BEFORE INSTALLATION

1. Hand fitting required.
2. Clean exhaust port before trying to assemble end of pipe that fits into port. May require sanding for a smooth fit.
3. Put front pipe on first with the rear pipe installed in a Y portion.
4. Then, twist rear pipe to match clearance of the brake cross bar #49-1034 and the crank #49-0914, then push in place.