

V-Twin Mfg.  
Auto Advance Distributor with Clamp  
Fits 1966-1969 FL  
VT #32-0546

**To Install:**

1. Make sure front cylinder is at top dead center on compression/ignition stroke.
2. Timing mark should be just coming into timing hole plug window.
3. Turn distributor so that the points are just about to open on the narrow lobe of the cam.