

**V-Twin Mfg.**  
**Black Fairing Mirror Set**  
**VT Part No. 34-1223**  
**Chrome Fairing Mirror Set**  
**VT Part No. 34-1224**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Installation Instructions:**

1. Removing outer fairing as per instructions listed in the OEM service manual.
2. Place template on inside of fairing as shown to locate mounting holes for mirror.
3. Begin by drilling a 1/8 inch pilot hole at each location marked on the template. For the center hole (2) where the 3/8 inch threaded stud passes through the fairing use a 13/32 inch diameter twist drill to drill the hole to its final size. For the alignment hole (1), use a 7/32 inch diameter twist drill to drill the hole to the final size.

**Note:** The flange nut is a self locking nut and must not be tightened more than 30 in-lbs.

4. Place mirror (2) in position and install backing plate (4) with the raised post (B) (with the L and R marking) toward the nut surface. Install the flange nut (6) and tighten nut to 20-30 in-lbs .
5. Position the mirror so the round auxiliary mirror is in the upper inside corner position.
6. Repeat for right side.
7. Reinstall outer fairing as per instructions listed in the OEM service manual.

