


V-Twin MFG. Cycovator Air Filter

VT No. 34-1290 and 34-1742

This is a custom application rider safety depends on proper installation and should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.


Installation Instruction:



1. Refer to the service manual and remove the OEM air filter cover and filter element. The hoses will be re used.



2. Remove the breather backing plate. The 2 breather bolts will be re used.




3. Attach the supplied support brackets to the cylinder heads using the OEM breather bolts. Install the spacers between the bracket and the cylinder head. **Do not tighten at this time.**



4. Trim 5/16" off of each hose.

5. Install the uncut (long) hoses end, into the supplied air filter element.



6. Install and tighten the filter element with the hoses onto the carburetor/throttle body using the provided screws and new gasket.




7. Using the supplied 1/4 inch bolts, lock washer and flat washer attach the breather brackets to the back of the filter element.



8. Torque the breather bolts to 22-24 ft-lbs..



9. Torque the 1/4" air filter mounting bolts to 40-60 inch-lbs.



10. Attach the hoses to the breather bolts.



11. Remove the outer gasket from the OEM filter cover and install the cover with the OEM bolt.