



VT No. 35-0135 Extended Float Bowl fits CV Carbs

1. Remove float bowl per factory manual.
2. Remove acc pump brass squirter and install taller unit.
3. Using a CA type glue or 640 Loctite--install overflow extension
4. Remove acc pump and install longer rod
5. Remove main jet and install jet extension--Install main jet.
6. Install new bowl gasket on float bowl and place spacer plate on bowl. Install bowl gasket on spacer and attach bowl assy to carb with new bolts supplied.

Notes: Make sure all fuel lines--fittings are secured and installed per factory manual. Check for fuel leaks!!

Special Note: Make sure that acc pump squirter hole is facing approximately 1/8" to left of bowl overflow. You may use a 6" scale and place it on flat surface of squirter and while holding it firmly place an awl or any small straight object at a 90 degree angle at the center of squirter, It should be approximately 1/8" to left of bow overflow.

IMPORTANT NOTE: IF SILVER NEEDLE JET FALLS OUT DURING REMOVAL OF JET HOLDER--MAKE SURE THAT THE LARGEST OPENING END OF THE NEEDLE JET GOES IN FACING UP TOWARD THE CV SLIDE NEEDLE!

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.