

OKO SHORTY CARBURETORS



WE SUGGEST REMOVING THESE NUTS & APPLYING LOCTITE TO ENSURE THEY DO NOT COME LOOSE.



**REMOVE NUT FROM LEFT SIDE AND APPLY LOCTITE ONTO THREADED BOLT AS SHOWN. FASTEN NUT BACK ONTO BOLT AND MAKE SNUG
*DO NOT OVER TIGHTEN***



REPEAT PROCESS ON RIGHT SIDE.