

OKO SHORTY CARBURETORS



WE SUGGEST REMOVING THESE NUTS & APPLYING LOCTITE TO ENSURE THEY DO NOT COME LOOSE.



REMOVE NUT FROM LEFT SIDE AND APPLY LOCTITE ONTO THREADED BOLT AS SHOWN. FASTEN NUT BACK ONTO BOLT AND MAKE SNUG

DO NOT OVER TIGHTEN



REPEAT PROCESS ON RIGHT SIDE.