

# OKO SHORTY CARBURETORS



**WE SUGGEST REMOVING THESE NUTS & APPLYING LOCTITE TO ENSURE THEY DO NOT COME LOOSE.**



**REMOVE NUT FROM LEFT SIDE AND APPLY LOCTITE ONTO THREADED BOLT AS SHOWN. FASTEN NUT BACK ONTO BOLT AND MAKE SNUG  
\*DO NOT OVER TIGHTEN\***



**REPEAT PROCESS ON RIGHT SIDE.**