

V-Twin Mfg.  
60 mm Chrome Tachometer Housing Kit  
VT Part No. 39-0202  
For use on 1980 & Up Models

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

**Installation Instructions:**

1. Connect the black wire on the tach to a convenient ground on the engine or battery. A good ground is critical for proper operation of the tach.
2. Connect the red wire on the tach to a switched 12-volt power source.
3. Connect the blue wire to the same switched 12-volt power source as the red wire if you want the tach light to be on continuously, or to the light terminal on the ignition switch.
4. Connect the green wire on the tach to the negative side of the coil, the tach lead on the ignition or to a tach adapter depending on your application. The negative side of the coil is the side leading to the ignition module. (On stock bikes this is usually a blue or pink wire.) The positive side of the coil supplies 12 volts from the ignition switch.

