

V-Twin MFG.

**For use on 1999 and later XL and Dyna (except FXDWG) models with 3 3/4 inch gauge
VT No 39-0223**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions

- 1. Clean and dry surface of gauge with rubbing alcohol to ensure cleanliness.**
- 2. Check fit. Peel adhesive backing from the back of the trim ring.**
- 3. Be sure to center the trim ring over the gauge and press trim ring firmly into position.**

