

V-Twin Mfg.
60 MM MINI ELECTRIC TACHOMETER
FITS 1978-UP; WITH BLACK FACE
VT Part No. 39-0392

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Remove existing Tachometer if applicable, according to service manual.
2. Mount new Tachometer in desired location. Be sure it does not interfere with the turning of the handlebars.
3. Connect the black wire on the tachometer to a convenient ground on the engine or battery. A good ground is critical for proper operation of the tachometer.
4. Connect the red wire on the tachometer to a switched 12-volt power source.
5. Connect the blue wire to the same switched 12-volt power source as the red wire if you want the tachometer light to be on continuously, or to the light terminal on the ignition switch.
6. Connect the green wire on the tachometer to the negative side of the coil, the tachometer lead on the ignition or to a tachometer adapter depending on your application. The negative side of the coil is the side leading to the ignition module. (On stock bikes this is usually a blue or pink wire.) The positive side of the coil supplies 12 volts from the ignition switch.
7. Start motorcycle and check for proper functioning of the tachometer.

